## WIRE GRID PANEL FOR BASIC UPIGHT

**PAGE 1 OF 1** 

**ASY 239** 

ASSEMBLY INSTRUCTION


Lift panel to the desired height on the upright. (Make sure the panel is level)

Slip the bottom hooks into the appropriate slots on the uprights.

Push the top of the panel toward the uprighs; lifting it to allow the top hooks to slip into the upright slots.

Allow the panel to drop down into the upright slots; locking the hooks in position.

ASSEMBLY COMPLETE





P.O. BOX 729 / TERRELL, TEXAS 75160 / 972.563.5744 / 800.776.2349

STORE FIXTURES P.O. BOX 177 / GOODWATER, ALABAMA 35072 / 256.839.6354 / 800.633.6282



REV#	ECN#	REVISION	BY	DATE	REV#	ECN#	REVISION	BY	DATE
A	4912R	evise layout, drawing & instruction	ММН	4/23/01					