


Common Parts


1 MAXI GRID FIXTURE PANEL (GPWFP)

FIXTURE PANELS ARE USED AS END SUPPORT.




2 MAXI GRID WIRE GRID SHELF WITH (GPWGS)

SHELF CAN BE USED ANYWHERE.




ANY OTHER WIRE SHELF MAY BE USED IN PLACE OF THIS COMPONENT

MAXI GRID HEAVY-DUTY WIRE TOP SHELF WITH LIP (GPHDWTS)



3 MAXI GRID REINFORCEMENT BAR (GPRB)

REINFORCEMENT BARS ARE USED TO SUPPORT WOOD SHELVES.



ANY OTHER REINFORCEMENT BAR MAY BE USED IN PLACE OF THIS COMPONENT
EXAMPLE: GPBRC & GPBRL


4 MAXI GRID FRONT KICKPLATE (GPGKB) (OPTIONAL)

PROTECTS ITEMS FROM SLIDING UNDER UNIT.




5 MAXI GRID WOOD SHELF (GPWS)

WOOD SHELVES SIT ON REINFORCEMENT BARS.



6 MAXI GRID ANTI-SWAY BRACES (GPASTBA)

ANTI SWAY BRACES ARE AT THE BACK FOR SUPPORT, AND REQUIRED TO STABILIZE SYSTEM. COMES IN PAIRS.



madix
ASY-80034922

P.O. BOX 729 TERRELL, TEXAS 75160
214-515-5400 / 800-776-2349


PAGE 1 OF 13 REV. 00
SAM ECM # 500000013495

INSTRUCTION SET A

THREE PEOPLE ARE NEEDED

TO INSTALL SYSTEM


- 1 STAND BOTH FIXTURE PANELS UP 48 INCHES APART. MAKE SURE HORIZONTAL WIRES ARE FACING THE SAME DIRECTION ON BOTH FIXTURE PANELS.



NOTE:
ALL MAXI GRID SECTIONS MUST HAVE LEFT TO RIGHT SUPPORT ON THE TOP AND BOTTOM OF EACH SECTION.

THIS CAN BE DONE USING **GPRB(NW)**, AS SHOWN BELOW
OR
ANY OTHER BAR OFFERED
OR
WIRE GRID SHELVES

- 2 IF USING WIRE GRID SHELF, HOOK BOTH PRONGS OF ONE SIDE OF THE TOP SHELF ON THE HORIZONTAL WIRE. THEN HOOK OTHER SIDE UNTIL SHELF IS INSTALLED (SEE NEXT PAGE FOR REBAR INSTALLATION).



ONE PERSON HOLDS EACH FIXTURE PANEL WHILE THIRD PERSON INSTALLS REBAR, KICKPLATE, OR SHELF. THIS IS REQUIRED UNTIL ANTI-SWAY BRACES ARE INSTALLED (SEE SHEET 4)



DETAIL A
SCALE 1 : 8


madix
ASY-80034922
P.O. BOX 729 TERRELL, TEXAS 75160
214-515-5400 / 800-776-2349
PAGE 2 OF 13 REV. 00
SAM ECM # 500000013495

- 3 INSTALL REBAR OR SIMILAR SUPPORT OPTIONS (3.1)
LOWER OTHER SIDE ONTO FIXTURE PANEL (3.2)
REPEAT STEPS FOR UPPER SUPPORTS (3.3)


NOTE:
ALL MAXI GRID SETIONS MUST HAVE LEFT TO RIGHT SUPPORT ON THE TOP AND BOTTOM OF EACH SECTION.

THIS CAN BE DONE USING **GPRB(NW)**, AS SHOWN BELOW
OR
ANY OTHER BAR OFFERED **OR**
WIRE GRID SHELVES

- 4 INSTALL FRONT KICKPLATE (4.1)
LOWER OPPOSITE SIDE OF KICKPLATE. (4.2)
SLIDE KICKPLATE TOWARDS OPPOSITE SIDE SO THAT THE PRONGS ARE ALSO ABOVE THE WIRES. LOWER PRONGS AND LOCK ONTO WIRE (4.3) (OPTIONAL)



- 3.1 POSITION ONE SIDE AT THE SECOND HORIZONTAL WIRE FROM THE BOTTOM. PLACE PRONGS SO THE FIRST VERICAL WIRE FROM THE BACK IS BETWEEN THEM
- 3.2 LOWER THE OTHER SIDE OF THE REBAR UNTIL IT IS IN PLACE
- 3.3 REPEAT STEPS 3.1 AND 3.2 FOR UPPER REBAR SUPPORTS (WIRE GRID SHELVING AND SIMILAR SUPPORT BAR OPTIONS MAY ALSO BE USED IN PLACE OF REBAR).



(OPTIONAL)

- 4.1 ANGLE KICKPLATE, AND SLIDE OVER HORIZONTAL WIRE
- 4.2 ROTATE OPPOSITE SIDE DOWN
- 4.3 SLIDE TOWARD OPPOSITE PANEL UNTIL LOCKED IN PLACE



madix
ASY-80034922


P.O. BOX 729 TERRELL, TEXAS 75160
214-515-5400 / 800-776-2349

PAGE 3 OF 13 REV. 00
SAM ECM # 500000013495


5 TO INSTALL WOOD SHELF (5.1) SLIDE WOOD SHELF AND (5.2) LOWER SHELF ONTO KICKPLATE AND REBAR TO INSTALL ADDITIONAL WOOD SHELVES SEE SHEET 4.

5.1 SLIDE WOOD SHELF INTO FRAME AT AN ANGLE

5.2 LOWER IT ONTO THE TOP OF THE KICKPLATE AND REBAR.





6 UNSCREW ANTI-SWAY BRACE SO IT IS FLUSH. HOOK ONE SIDE OF THE BRACE OVER ANY WIRE IN THE TOP THIRD SECTION OF THE GABLE. HOOK THE OTHER SIDE OF THE BRACE TO ANY WIRE IN THE BOTTOM THIRD SECTION OF OPPOSITE GABLE. REPEAT TO INSTALL SECOND ANTI-SWAY BRACE. BRACES SHOULD FORM AN X ON THE BACK OF THE UNIT. TIGHTEN TURN BUCKLES ON BRACES TO SQUARE UNIT. **DO NOT OVER-TIGHTEN TURNBUCKLE!**




7 TO INSTALL ADDITIONAL TOP SHELVES HOLD SHELF AT AN ANGLE. SLIDE SHELF INTO THE FRAME OF THE UNIT (8.1) SLIDE PRONGS PAST HORIZONTAL WIRES. (8.2) LOWER OPPOSITE SIDE OF SHELF SO THAT THE SHELF IS LEVEL, AND LOWER AND LOCK ON PLACE. (8.3)

7.1 HOLD SHELF AT AN ANGLE, AND SLIDE IT INTO THE FRAME OF THE UNIT, WITH ONE SIDE OF THE SHELF PRONGS AT THE DESIRED HEIGHT. **DO NOT LOCK!!**




7.2 VERTICAL GABLE WIRES SHOULD BE BETWEEN PRONGS. SLIDE PRONGS PAST HORIZONTAL WIRES.

7.3 LOWER OPPOSITE SIDE OF SHELF SO THAT THE SHELF IS LEVEL. SLIDE SHELF BACK SO THAT THE PRONGS ARE ABOVE THE HORIZONTAL WIRES. LOWER AND LOCK INTO PLACE.




8 TO INSTALL A WOOD SHELF, ANYWHERE IN THE UNIT, YOU MUST FIRST INSTALL TWO REBARS. HOLD BAR AT AN ANGLE. SLIDE BAR INTO THE FRAME OF THE UNIT, WITH ONE SIDE AT THE DESIRED SHELF HEIGHT. DO NOT LOCK! VERTICAL WIRE SHOULD BE BETWEEN PRONGS. SLIDE PRONGS PASSED HORIZONTAL WIRES. LOWER THE OPPOSITE SIDE OF THE BAR SO THAT THE BAR IS LEVEL. SLIDE BAR BACK INTO PLACE, SO THAT PRONGS ARE OVER THE HORIZONTAL WIRES. LOWER AND LOCK INTO PLACE. REPEAT STEP FOR SECOND REBAR. FOLLOW STEP 5 TO INSTALL WOODEN SHELF.




9

TO ADD ADDITIONAL UNITS STAND ANOTHER FIXTURE PANEL 48" FROM THE EXISTING UNIT. MAKE SURE HORIZONTAL WIRES ARE FACING THE SAME DIRECTION AS THE HORIZONTAL WIRES IN THE FIRST UNIT. **NOTE:** ONLY ONE FIXTURE PANEL IS NEEDED TO BUILD THE SECOND UNIT. THE SECOND UNIT WILL SHARE THE OUTWARD FACING FIXTURE PANEL FROM THE FIRST UNIT. USING THIS SHARED FIXTURE PANEL, REPEAT PREVIOUS STEPS TO COMPLETE THE SECOND UNIT.



DETAIL D
SCALE 1 : 10



madix
ASY-80034922


P.O. BOX 729 TERRELL, TEXAS 75160
214-515-5400 / 800-776-2349

PAGE 7 OF 13 REV. 00

SAM

ECM # 500000013495

10 TO COMPLETE THE SECOND BASIC UNIT, YOU WILL NEED TO ADD A TOP SHELF USING THE SHARED PANEL FIXTURE FROM THE FIRST UNIT REPEAT STEP 6.
NOTE: ANTI SWAY BRACES ARE NOT NEEDED IN THE SECOND UNIT. THEY ARE ONLY NEEDED ON EVERY OTHER UNIT.



madix
ASY-80034922

P.O. BOX 729 TERRELL, TEXAS 75160
214-515-5400 / 800-776-2349

PAGE 8 OF 13 REV. 00


SAM ECM # 500000013495

INSTRUCTION SET B



1 BEFORE STARTING INSTALLATION, YOU MUST FIRST IDENTIFY THE TWO TYPES OF FIXTURE PANELS. THERE ARE **FOOTPLATED PANELS**, AND **NON-FOOTPLATED PANELS**. NOTICE THE "B" ON THE ENDS OF THE PANELS (SEE DETAIL "J"). THIS INFORMATION WILL BE NEEDED IN FUTURE STEPS.

2 STAND ONE NON-FOOTPLATED FIXTURE PANEL UPRIGHT IN THE APPROXIMATE DESIRED LOCATION WITH "B" SIDE ON FLOOR. ALSO NOTICE HORIZONTAL GABLE WIRES. DO THEY SIT BEHIND OR IN FRONT OF VERTICAL WIRES? YOU WILL NEED THIS INFORMATION FOR FUTURE STEPS


NON-FOOTPLATED FIXTURE PANEL




FOOTPLATED FIXTURE PANEL




DETAIL J
SCALE 1 : 3



DETAIL K
SCALE 1 : 3



HORIZONTAL WIRE SITS IN FRONT OF VERTICAL



DETAIL L
SCALE 1 : 8



madix
ASY-80034922





P.O. BOX 729 TERRELL, TEXAS 75160
214-515-5400 / 800-776-2349

PAGE 9 OF 13 REV. 00




SAM ECM # 500000013495

3 STAND A FOOTPLATED FIXTURE PANEL PARALLEL TO THE FIRST FIXTURE PANEL, WITH THE FOOTPLATE ON THE FLOOR. **MAKE SURE THE HORIZONTAL WIRES ARE FACING THE SAME DIRECTION AS THE HORIZONTAL WIRES ON THE FIRST FIXTURE PANEL.**

4 BOLT FOOTPLATE TO THE FLOOR. INSTALL SHELVES AND ACCESSORIES AS USUAL. WHEN ADDING ADDITIONAL UNITS TO THIS FRAME, ROTATE FOOTPLATED AND NON-FOOTPLATED FIXTURE PANELS AS YOU WISH. BUT MAKE SURE THE CORRECT FIXTURE PANEL SIDE IS ON THE FLOOR! ("B" SIDE OR FOOTPLATE SIDE AS DESCRIBED IN PREVIOUS STEPS.



5 IF YOU ARE NOT USING FOOTPLATED FIXTURE PANELS, ENSURE ALL FIXTURE PANELS IN THE RUN HAVE THE "B" SIDE TO THE FLOOR. LINE WIRES AS DIRECTED IN STEP 3. INSTALL SHELVES AND ACCESSORIES AS USUAL.



MAXI GRID ANTI-SWAY BRACES USAGE GUIDE

GPASTBA(NL)(OPT)


GPASTB - MAXI GRID ANTI-SWAY TURNBUCKLE ASSEMBLY

NL - NOMINAL LENGTH 64" OR 104"

OPT - BLANK = 48"W


36 = SPECIFIED LENGTH FOR 36" SECTION

FIXTURE HEIGHT	FIXTURE WIDTH	
	36"	48"
50"	67	67
62"	67	67
76"	67	67
88"	67	67
100"	67	104
124"	104	104
148"	104	104



GPASTBA INSTALLATION

1. STAND FIXTURE PANELS UPRIGHT
2. INSTALL TOP SHELF AND KICKPLATE, IF APPLICABLE, AT TOP AND BOTTOM OF FIXTURE
3. HOOK AB RODS NEAR TOP OF FIXTURE AND BRING TURNBUCKLES END TO OPPOSITE FIXTURE PANEL. TIGHTEN TURNBUCKLE END JUST ENOUGH TO HOLD FIXTURE UPRIGHT (THE UNIT IS NOW SELF STANDING).
4. INSTALL REMAINING FIXTURE COMPONENTS (SHELVES, SLATWALL, ETC.).
5. FULLY TIGHTEN GPASTBA'S WHILE CHECKING WITH LEVEL TO ENSURE FIXTURE PANELS ARE PLUMB.



* (2) GPASTBA'S NEEDED PER (1) UNIT.
* GPASTBA'S ARE NEEDED EVERY OTHER FIXTURE WHEN IN A RUN (SEE CHART).



madix
ASY-80034922

P.O. BOX 729 TERRELL, TEXAS 75160
214-515-5400 / 800-776-2349

PAGE 12 OF 13 REV. 00

SAM

ECM # 500000013495

LOAD CAPACITY INFORMATION

STATIC LOAD AND EVENLY DISTRIBUTED

MAXIMUM LOAD CAPACITY IN POUNDS FOR SHELVES & REBARS	
GPRB48	200 LBS /PAIR
GPRBC48	100 LBS /PAIR
GPRBL48	150 LBS /PAIR
GPLBSS	40 LBS /4 BKT
GPWGS4822	40 LBS
GPWBL5482404	40 LBS
GPWTS361204	40 LBS
GPHDWGS4818	200 LBS
GPHDWTS481804	200 LBS

MAXIMUM LOAD CAPACITY IN POUNDS FOR WIRE FIXTURE PANELS	
GPWFP	1000 LBS / WIRE FIXTURE PANEL



madix
ASY-80034922
P.O. BOX 729 TERRELL, TEXAS 75160
214-515-5400 / 800-776-2349

PAGE 13 OF 13	REV. 00
SAM	ECM # 500000034922